

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiència Energètica / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energoefektivitātes

Table with 16 columns (PF, IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV) and multiple rows of technical specifications for a hood. The table includes model information (S M FABER P1297), energy efficiency ratings (AEC, FDE, LE, LEC, GFE, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps), and performance metrics (Qbep, Wbep, WL, Emiddle, Lwa) along with detailed installation and safety instructions in multiple languages.

