

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual – Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with 12 columns: PF, IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV. Rows include product info (S, M), energy consumption (AEchood, EEC, FDEhood, FDEC, LEhood, LEC), filtration (GFEhood, GFEC), airflow (Qmin, Qmax, Qboost), power (P0, Ps, PI), efficiency (EELhood, Ebep, Qmax, Wbep, WL, Emiddle, Lwa), and lighting (WL, Emiddle, Lwa). Each row contains technical specifications and their translations in multiple languages.

