

Manuale d'uso - Effizienz Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiència Energètica / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual – Energieeffektivitet Руководство - Энергоэффективность / Käsi raamat - Energiatõhususe / Rokasgrāmata - Energoefektivitātes

Table with 15 main columns: PF, IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV. Each column contains technical specifications and performance data for the FABER P2526 hood. It includes sections for power consumption, efficiency (AEC, FDE, LE, LEC, GFE, GFEC), air flow (Qmin, Qmax, Qboost), power (P0, Ps), and noise (F, EEL, QBep, P, W, WL, Emiddle, Lwa). It also features detailed instructions in multiple languages (EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU) and technical drawing information.

