

Manuale d'uso - Effizienz Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual – Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with columns: Model (PF FABER), Energy Efficiency (AEC/FDE/FDEC/LEH/LEC/GFE/GFEC/Qmin/Qmax/Qboost/Qbmin/SPEmin/SPEmax/SPEboost/P0/Ps), Power (PI), Energy Consumption (F), Air Flow (Qbep/Qmax/Wbep/WL/Emiddle/Lwa), Lighting (WL/Emiddle/Lwa), and Efficiency (Lwa). Each row contains technical specifications in multiple languages.

