

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual – Energieeffektivitet Руководство - Энергоэффективность / Käsiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with 13 columns (PF, IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV) and multiple rows. Rows include manufacturer info (FABER), energy efficiency classes (AEC, EEC, FDE, FDEC, LE, LEC, GFE, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps, PI, F, Qbep, Ebep, Qmax, Wbep, WL, Emiddle, Lwa), and safety instructions (CONSIGLI PER IL RISPARMIO ENERGETICO, CONSEILS POUR L'ECONOMIE ENERGETIQUE, RATSCHLÄGE ZUR ENERGIEERSPARUNG, TIPS VOR ENERGIEBERSPARING, CONSEJOS PARA EL AHORRO DE ENERGÍA, CONSELHOS PARA POUPAR ENERGIA, RÅD FÖR ENERGIBESPARING, ENERGIÅSÅSTUNING, REKOMENDACIJI PO EKONOMIJI ENERGIJE, REKOMENDACIJI ZA UŠTEDNOST ENERGIJE, PADOMI ENERGIJAS TAUPĪŠANAI). Each row contains technical specifications and descriptions in multiple languages.

