

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with 15 columns (PF, IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV) and multiple rows detailing product specifications and energy efficiency metrics for the FABER P1768 hood. Rows include energy efficiency classes (AEChood, EEC, FDEhood, FDEC, LEhood, LEC, GFEhood, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps, PI, F, Qbep, Pbeep, Qmax, Wbep, WL, Emiddle, Lwa), power consumption (P0, Ps, PI), and noise level (Lwa). Each row contains values in different units and detailed descriptions in multiple languages.

Посібник користувача - Energoefektivitatis / Vadovas - Energijos vartojimo efektyvumo / Manwal ghall-Utent - Effiċjenza fl-Energija / Kézi - Energiahatékonyaság / Příručka - Energetická účinnost / Průručka - Energetická účinnost / Рríruck - Energetická účinnost / Navodilo - Energetska učinkovitost / Εγχειρίδιο - Ενεργειακή Αποδοτικότητα / Manuel - Energi Verimliliği / Наръчник - Энергийна ефективност / Упутство - Энергетска ефикасност / Lámhleabhar Úsáideoir - Éifeachtúlacht Fuinnimh

Table with 13 main columns (S, M, AEChood, EEC, FDEhood, FDEC, LEhood, LEC, GFehood, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, PO, Ps, F, EEIhood, Qbep, Pbep, Qmax, Wbep, WL, Emiddle, Lwa) and 13 sub-columns (UA, LT, MT, CZ, SK, RO, PL, HR, SL, GR, TR, BG, SR, GA) containing technical specifications for the FABER P1768 vacuum cleaner.