

Manuale d'uso - Effizienz Energetica / User Manual - Energy Efficiency / Manuel de l'utlisateur - L'efficacit  energ t que / Handbuch - Energieeffizienz / Handboek - Energie-effici ntie Manual - Eficiencia Energ tica / Manual - Efici ncia Energ tica / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet / Руководство - Энергоэффективность / K siraamat - Energiat hususe / Rokasgr mata - Energoefektivit tes

Table with columns: Feature (PF), Value (FABER, 335.0502.095, P1381), Unit (kWh/a, lux/Watt, %), and 15 languages (IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV). Rows include energy consumption (AEchood, EEC, FDEhood, FDEC, LEhood, LEC, GFEhood, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps), lighting (PI, F, EEhood, Qbep, Bbep, Qmax, Wbep, WL, Emiddle, Lwa), and efficiency (EElhood, Qmax, Wbep, WL, Emiddle, Lwa). Includes technical descriptions in multiple languages.

